



## TrimTrac with VAM User Installation

### Elements:

- 1) TrimTrac device.
- 2) GPS Antenna (if required).
- 3) Power / IO Connector (VAM module).

### Instructions:

- 1) Mount the device in a secure place in your asset/car.
- 2) Keep the GPS antenna connected at all times (if required).
- 3) Ensure the GPS antenna (external or internal) is mounted face up with a clear view of the sky, not obstructed by metal.
- 4) Power connection (10V to 24V):

**Red cable** → Power supply  
**Black cable** → Ground

- 5) Connect the red power cable to a constant power source (required).
- 6) Install a **5 Amp** fuse on the power line (red cable).
- 7) The yellow wires are not used.

