



This antenna mounting bracket is designed for installation on these specific vehicles:

Dodge Ram 1500/2500/3500 2002-2008

Ford Explorer 2011-2014

Ford Police Interceptor 2011-2014

Model#: DGANTPF

Tools Required:

10mm socket and driver, or 10mm box end wrench

Install location:

Left front fender



Please Read: Always check for continuity between the bracket and chassis ground. If there is a problem with grounding, place the provided star washer between the bracket and the fender.

Step 1) Set the parking brake. Open hood and locate 10mm bolt near the back of the front left fender. Remove bolt.

Step 2) Align the antenna bracket with the bolt hole. Reinstall the bolt and tighten.

Step 3) Insert the NMO or required connector to mate with the antenna and tighten securely.



NCG Company may not be held liable for any damage to the vehicle before, during or after the installation or removal of this antenna bracket.
NCG may not be held liable for any personal injury resulting from accident or improper installation.



National Communications Group Co., Ltd
Chino, CA 800-962-2611
Fax: 909-393-6133
www.natcommgroup.com