



5757 Ravenswood Road
Ft. Lauderdale, FL 33312
+1 (954) 981-3333
+1 (954) 983-5087 Fax
www.acrelectronics.com
info@acrelectronics.com

Sea Shelter™₄

Mounting Template
Y1-06-0299 A



CAUTION: Category I brackets must be mounted free from obstruction to allow the beacon to automatically float free from the vessel in case of sinking. The Sea Shelter™₄ can be mounted on a vertical surface with the beacon antenna pointed skyward or a horizontal surface with the beacon face up. Avoid mounting locations that subject the bracket to breaking waves. Avoid structures like dodgers or cabin tops that could trap the beacon upon deployment.